AIR BARRIERS AN EMERGING MARKET ASHRAE 90.1 NEW 2007 INSULATION REQUIREMENTS

Keith Sportack
President
Pace Representatives Inc

www.pacerepresentatives.com

50 Redfield Street Boston MA 02122 617-342-7072

STATE OF CT HOUSE BILL 7432

- Sec. 78. Section 29-256a of the general statutes is repealed and the following is substituted in lieu thereof (*Effective October 1, 2007*):
- [The] (a) On and after January 1, 2008, the State Building Inspector and the Codes and Standards Committee shall revise the State Building Code to require that buildings and building elements, including residential, be designed to provide optimum costeffective energy efficiency over the useful life of the building. Such revision shall meet the American Society of Heating, Refrigerating and Air Conditioning Engineers Standard 90. 1 for new construction.

WHO IS ASHRAE

ASHRAE Society Profile

ASHRAE, the American Society of Heating, Refrigerating and Air-Conditioning Engineers, is an international organization of over 50,000 persons with chapters throughout the world. The Society is organized for the sole purpose of advancing the arts and sciences of heating, ventilation, air conditioning and refrigeration for the public's benefit through research, standards writing, continuing education and publications.

ASHARE 90.1 2007 NEW INSULATION REQUIREMENTS

Figure 3 Vancouver Winnipeg Toronto Boston Chicago Denver St.Louis Wilmington Atlanta Warm-Humid Below white line

Houston

Zone 1 includes Hawaii, Guam, Puerto Rico, and the Virgin Islands

Miami

All of Alaska in Zone 7 except for the following Boroughs in Zone 8:

Dellingham

North Slope

Fairbanks N. Star


Northwest Arctic Southeast Fairbanks

Wade Hampton

Yukon-Koyukuk


CLIMATE ZONE 5 MA AND SOUTH TO NORTH NJ

		Non-residential		Residential		Semi-heated	
	Opaque Elements		Proposed	Current	Proposed	Current	Proposed
Roofs							
	Insulation Entirely Above Deck	R-15ci	R-20ci	R-15ci	R-20ci	R-5ci	R-7.6ci
	Metal Buildings	R-19	R-13 + R-13	R-19	R-13 + R-13	R-10	R-13
	Attic and Other	R-30	R-38	R-38	NC	R-19	NC
Walls, A	Above Grade						
	Mass	R-7.6ci	R-11.4ci	R-11.4ci	R-13.3ci	NR	R-5.7ci
	Metal Building	R-13	R-13 + R-13	R-13 + R-13	R-13 + R-13	R-11	R-13
	Steel Framed	R-13 +	R-13 +	R-13 +	NC	R-13	NC
		R-3.8ci	R-7.5ci	R-7.5ci			
	Wood Framed and Other	R-13	R-13 +	R-13	R-13 +	R-13	NC
			R-3.8ci		R-7.5ci		




				Temperature		Accum			
	Common and Name a	- 1-1-1	D \/=!	Rep	۱ ۱	Interface	Actual	Dewpnt	(oz/day-sqft)
<u> </u>	Component Name		Thickness R-Value		-	-A	75.00	36.94	0.000
A	Interior Air Film	0.100	0.68	0.001		AB	72.93	36.94	0.000
В	Drywall .625in	0.625	0.56	0.023		BC	71.22	36.79	0.000
С	R-13 Fiberglass Batt	3.500	13.00	0.010		_ <u>cŏ</u>	31.55	36.73	* 0.067
D	DENS-GLASS GOLD .5in	0.500	0.56	0.043		T DE	29.84	36.45	* 0.037
E	Asphalt Felt 15#	0.100	0.10	1.000		I EF	29.54	29.18	0.000
F	CAVITYMATE Insulation	1.500	7.50	1.350		FG	6.65	15.54	* 0.002
G	Wall Air Space NonRefl	0.750	1.01	0.006		GH	3.57	15.45	* 0.002
Н	Brick Common 4in	4.000	1.00	1.300		HI	0.52	-25.10	0.002
1	Outside Air Film Winter	0.100	0.17	0.001			0.00	-25.10	0.000
J		, i	1			JK	0.00	-23.13	0.000
K			(I KL			
L	1	, , , , , , , , , , , , , , , , , , ,	(<u></u>		}	
<u>-</u>	TOTAL	11.175	24.58	3.734			<u> </u>	LL	

ASHRAE 90.1 2007 ZONE 5 Cavity Wall, R-13 + R-5.7 ci




ASHRAE 90.1 2007 ZONE 5 Cavity Wall, R-13 + R-5.7 ci



BEST PRATICE WALL Cavity Wall, 0 + R-12 ci

Air & Vapor Barrier + Exterior Insulation



What is driving the market?

- What is driving the market?
 - Building Science for the total wall

- What is driving the market?
 - Building Science for the total wall
 - Cost of energy

- What is driving the market?
 - Building Science for the total wall
 - Cost of energy
 - Mold

- What is driving the market?
 - Building Science for the total wall
 - Cost of energy
 - Mold
 - 15 years of proven success in Canada, along with the case studies to validate it


- What is driving the market?
 - Building Science for the total wall
 - Cost of energy
 - Mold
 - 15 years of proven success in Canada, along with the case studies to validate it
 - States like MA adopting air barriers back in 2000


- What is driving the market?
 - Building Science for the total wall
 - Cost of energy
 - Mold
 - 15 years of proven success in Canada, along with the case studies to validate it
 - States like MA adopting air barriers back in 2000
 - ASHRAE 90.1-2008 adopting air barriers standards for 2008

 How did we use to build walls 100 years ago?

- How did we use to build walls 100 years ago?
- They were not energy efficient but they also did not have mold issues for the most part.

Masonry Wall without insulation






How have we built walls over the last 20 years?

- How have we built walls over the last 20 years?
- We added insulation, vapor barriers, and got rid of the mass and lightened the wall


Wall Design

Typical Wall Design




Wall Design

Typical Wall Design



Moisture Drive



Taken from "Builder's Guide" by Lstibburek, Joseph of Building Science Corporation, Westford, MA, July 2000.

Moisture Drive

Moisture in Wall Assemblies

■ You don't want this to occur!






How do you build a wall correctly with air barriers in all climates?

How do you build a wall correctly with air barriers in all climates?

- There needs to be an understanding of:
 - Air barrier placement in the wall
 - Insulation
 - Vapor barrier requirement


Wall Design

- Building Science experts
 recommend the exterior of the
 wall be built as tight as possible
 in Severe Cold, Cold, Hot, and
 Mixed Humid Climates.
- Leave the inside permeable enough to dry.
- To do this:
 - **First**, take the fiberglass insulation/interior vapor retarder out of the wall cavity and use insulated sheathing on the exterior.



BEST PRATICE WALL Cavity Wall, 0 + R-12 ci

Air & Vapor Barrier + Exterior Insulation



BEST PRATICE WALL Cavity Wall, 0 + R-12 ci

Air & Vapor Barrier + Exterior Insulation

Dewpoint is on exterior side of Nair & vanor harrier Summer Time **Winter Time** exteriorestide offairdistapor Drive sensitive materials!


EXTERIOR

Stud cavity can dry


Vapor Drive

NTERIOR

54% IMPROVED WALL R- 22.51



54% IMPROVED WALL R- 22.51





Sample Details

Wagdy Anis, AIA

Shepley Bulfinch Richardson and Abbott, Task Force Chair

Mark Kalin, FAIA, FCSI

Kalin Associates, Inc.

Steven Rigione

HKT Architects Inc.

Lance Robson, AIA

Building Envelope Technologies Inc.

Keith Sportack

Pace Representatives

Jeff Wade, AIA

ADD Inc

with general review by:

Len Anastasi, CSI

Lennel Specialties

Vince Camalleri, AIA

Simpson, Gumpertz and Heger

Ken Crocco, AIA

ArchiTech Consulting Inc., Chicago Chapter AIA

Richard Keleher, AIA, CSI

Shepley Bulfinch Richardson and Abbott

Don Klema, AIA

Kallmann McKinnell and Wood Architects

Joseph Lstiburek, PhD., P. Eng.

Building Science Corporation

Ned Lyon, P.E.


Simpson, Gumpertz and Heger

Fred Nashed, AIA

Architectural Consulting Services

Oscar Padjen, AIA

Padjen Architects, Inc.



Thermal Break

☐ Effective R-value = R-value x Correction Factor

Nominal Framing	Nominal Insulation	Correction	Effective
Depth	R-Value	Factor	R-Value
4" @ 16" o.c.	R-11	0.50	R-5.5
	R-13	0.46	R-6.0
	R-15	0.43	R-6.4
4" @ 24" o.c.	R-11	0.60	R-6.6
	R-13	0.55	R-7.2
	R-15	0.52	R-7.8
6" @ 16" o.c.	R-19	0.40	R-7.6 ²
	R-21	0.35	R-7.4
6" @ 24 o.c.	R-19	0.45	R-8.6
	R-21	0.43	R-9.0


¹Data source: Adopted from ASHRAE/IES Standard 90.1-1989 User's Manual, November 1992, p. 8-64.
²Recent analysis of tested assemblies indicates an R-value of 7.1 for R-19 insulation in nominal 6" framing at 16" on center, though the correction factor published in Standard 90.1 currently offers a higher credit


[□] Recent analysis of tested assemblies indicates an R-value of **7.1** for R-19 insulation in normal 6" framing at 16" on center, though the correction factor published in Standard 90.1 currently offers a higher credit.

WHY ASHRAE 90.1 2008 IS ADOPTING AIR BARRIERS

WHY IS ASHRAE 90.1 2008 ADOPTING AIR BARRIERS

 US Department of Energy sponsored study on air barriers by National Institute of Standards and Technology (NIST) June 2005





THREE MAJOR TYPES OF AIR BARRIERS THAT WILL MEET THE PROPOSED 2007 ASHRAE REQUIREMENTS

THREE MAJOR TYPES OF AIR BARRIERS THAT WILL MEET THE PROPOSED 2008 ASHRAE REQUIREMENTS

- Sheet known as peel—and-stick
- Liquid applied
 - Roll on single component
 - Spray on multi-component

SHEET PEEL-AND-STICK









SINGLE COMPONET ROLL ON







SINGLE COMPONET TROWEL ON



SINGLE COMPONET SPRAY APPLIED













Acrobat Document

QUESTIONS